

List of devices compatible with Cook4me Connect

Android supported devices

This application is designed to work with a wide range of Android™ smartphones. Support depends on your device brand, model and Android version.

To use this application, your smartphone or tablet must at least be running Android™ 4.3 or higher and have Bluetooth Low Energy (BT4.0).

Warning: some models earlier than ANDROID 6 are not compatible (see list under table):

The list of devices tested and operational with MyCook4me and Cook4me Connect is set forth below.

Brand	Model	Android version tested	Type
Asus	Nexus 7	5.1.1	Tablet
HTC	Nexus 9	5.0.1	Tablet
HTC	Nexus 9	5.1.1	Tablet
HTC	One (M8)	5.0.1	Smartphone
Huawei	Nexus 6	5.1.1	Smartphone
Huawei	Ascend Mate 7	4.4.2	Smartphone
LG	G3	4.4.2	Smartphone
LG	G3	5.0.1	Smartphone
LG	Nexus 5	5.1.1	Smartphone
LG	G Pad 7.0	4.4.2	Tablet
LG	G Pad 10.1	5.0.2	Shelf
Motorola	Moto G	5.0.2	Smartphone
Motorola	Moto G 2014	5.0.2	Smartphone
Motorola	Moto E	5.0.2	Smartphone
Nvidia	Shield Tablet WiFi	5.0.1	Tablet
Samsung	G2	4.4.2	Smartphone
Samsung	Galaxy A3	5.0.1	Smartphone
Samsung	Galaxy A3	5.0.2	Smartphone
Samsung	Galaxy Alpha	5.0.2	Smartphone
Samsung	Galaxy Grand Neo plus	4.4.4	Smartphone
Samsung	Galaxy Note 3	4.4.2	Smartphone
Samsung	Galaxy Note II	4.4.2	Smartphone
Samsung	Galaxy S3	4.3.0	Smartphone
Samsung	Galaxy S3	4.4.4	Smartphone
Samsung	Galaxy S4	4.4.2	Smartphone
Samsung	Galaxy S4	5.0.1	Smartphone
Samsung	Galaxy S4 LTE Advance	4.4.2	Smartphone
Samsung	Galaxy S4 mini	4.4.2	Smartphone
Samsung	Galaxy S5	4.4.2	Smartphone

Brand	Model	Android version tested	Type
Samsung	Galaxy S5	5.0.1	Smartphone
Samsung	Galaxy S5 mini Duos	4.4.2	Smartphone
Samsung	Galaxy S6	5.0.2	Smartphone
Samsung	Galaxy S6	5.1.1	Smartphone
Samsung	Galaxy S6 Edge	5.1.1	Smartphone
Samsung	Galaxy Tab Active 8	4.4.2	Tablet
Samsung	Galaxy Tab Pro 8.4	4.4.2	Tablet
Samsung	Galaxy Tab S 10.5	4.4.2	Tablet
Samsung	Galaxy Tab S 10.5	5.0.2	Tablet
Samsung	Galaxy Tab 4 10.1	5.0.2	Tablet
Samsung	Galaxy Grand Prime	4.4.4	Smartphone
Samsung	Galaxy Tab 3 Lite	4.4.4	Tablet
Samsung	Galaxy Tab 4 7.0	4.4.2	Tablet
Samsung	Galaxy Note 10.1 (2014)	4.4.2	Tablet
Samsung	Galaxy Note Pro 12.2	4.4.2	Tablet
Samsung	Galaxy Tab S 8.4	4.4.2	Tablet
Samsung	Galaxy Tab Pro 10.1	4.4.2	Tablet
Samsung	Galaxy Note 4	5.0.1	Smartphone
Samsung	Galaxy Note 3 Neo LTE+	4.4.2	Smartphone
Samsung	Galaxy Ace 4	4.4.4	Smartphone
Samsung	Galaxy Core Prime	4.4.4	Smartphone
Samsung	Galaxy Tab 3 Lite 7.0 WiFi	4.4.4	Tablet
Samsung	Galaxy Tab 4 8.0 LTE	4.4.2	Tablet
Samsung	Galaxy Tab A 9.7	5.0.2	Tablet
Sony	Xperia Z3 Compact	5.0.2	Smartphone
Sony	Xperia Z1 Compact	5.0.2	Smartphone
Sony	Xperia Z2	4.4.4	Smartphone
Sony	Xperia Z2 Tablet Wi-Fi	4.4.2	Smartphone
Sony	Xperia M2 LTE	4.4.4	Smartphone
Sony	Xperia Z3	4.4.4	Smartphone
Sony	Xperia Z4 Tablet	5.0.2	Tablet
Wiko	Lenny 2	4.4.2	Smartphone
Wiko	Highway 4G	4.4.0	Smartphone
Xiaomi	Redmi 2	4.4.4	Smartphone

Some models earlier than ANDROID 6 are not compatible such as:

Brand	Model:	Android version
Google	Nexus 5, 6, 7 and 9	6.0

iOS supported devices

Brand	Model:	iOS version	Type
Apple	iPhone 4S	7.0 or higher	Smartphone
Apple	iPhone 5	7.0 or higher	Smartphone
Apple	iPhone 5S	7.0 or higher	Smartphone
Apple	iPhone 5C	7.0 or higher	Smartphone
Apple	iPhone 6	8.0 or higher	Smartphone
Apple	iPhone 6+	8.0 or higher	Smartphone
Apple	iPhone 6S	9.0 or higher	Smartphone
Apple	iPhone 6S+	9.0 or higher	Smartphone
Apple	iPad 3rd Gen+	7.0 or higher	Tablet
Apple	iPad 4rd Gen+	7.0 or higher	Tablet
Apple	iPad Air	7.0 or higher	Tablet
Apple	iPad Air 2 nd Gen	8.0 or higher	Tablet
Apple	iPad mini	7.0 or higher	Tablet
Apple	iPad mini 2	7.0 or higher	Tablet